

Wild Vision Manual

[How to install the Wild Vision App](#)

[How to pair optical device and mobile device](#)

[How to control your optical device using a mobile device](#)

[How to update firmware of your optical device](#)

[How to upload recorded files to a mobile device](#)

[How to export and share recorded files via mobile applications](#)

[Legal Compliances and Disclaimers](#)


How to install the Wild Vision App

Step 1

Download the Wild Vision App from Google Play.

Step 2

Tap Wild Vision icon on your Android device to start the Wild Vision Application.




How to pair optical device and mobile device

Step 1

Launch the Wild Vision App.


Step 2

Tap "Login".



Step 3



Choose your preferred login method.





Step 4

Turn on your device by pressing the power button.


Step 5



Find the unique Wi-Fi password in your Pulsar device's main menu section "Wi-Fi Settings"  → "Password Setup"  .

Step 6

Turn on Wi-Fi in the Wi-Fi Settings  menu of your device. A Wi-Fi icon in the status bar will start to flicker, then a question mark will appear next to it  .

Step 7




- On your smartphone go to "Settings" → "Wi-Fi" and select the network with your Pulsar device's name and serial number in your phone.
- Click "Connect".
- Type in the device's Wi-Fi password in the prompt box in your smartphone.
- An icon  in the status bar of your Pulsar device will change to an icon . Ignore "no internet connection" messages (if any).

Step 8

Return to the Wild Vision App.

Step 9

Tap "Connect device" button.




How to control your optical device using a mobile device

Step 1


Tap "Viewfinder".

In the "Viewfinder", you can see the live broadcasted image from the device, change your device's settings, turn on video recording and take photos.





Step 2

To access the device's function, tap icons above and below the image from the device.



Step 3

Tap Settings icon  in the top right corner to change other settings of your optical device, it will open Settings tab.






Step 4

At the bottom of the screen, tap  to capture a photo or tap  to record a video.

The image in the viewfinder, as well as the recorded photos and videos, will not contain interface elements.





To enable the overlay graphics in the viewfinder, go to "General Settings"  → "Overlay Media Mode"  in the device's main menu. Select "Media with overlay" mode.




Step 5

Motion detection function

To track moving objects in the field of view of the device, go to the Settings menu and briefly press the switch next to the "Motion detection" item to the position .






Moving objects will be indicated by a green frame.



Below you can adjust feature settings:

- Select sensitivity level of motion detection.





- Enable automatic passive mode at set time intervals. In passive mode the screen is locked to avoid accidental exit from the application.
- Enable  /disable  vibro or sound notifications.
- Automatically activate video recording when a moving object is detected.

How to update firmware of your optical device

Step 1

Pair your optical device and your mobile device via Wi-Fi.



Step 2


In the Wild Vision app, open the "Settings"  tab and select your device.

Step 3

Tap "Check firmware update".

If you don't have internet access via mobile data, disconnect your phone from your device's Wi-Fi network and connect to internet.

If new firmware is available the link will change to "Install firmware update".



Step 4

Connect to your optical device.

Step 5

Tap "Install firmware update".

The application transfers firmware to your optical device, the process may take up to several minutes.

Once update installation is completed, the firmware number in the device information will change.

Important!

- Before performing the update please make sure that your Pulsar device is charged more than 50%.
- During the update, do not switch to other tabs or applications.

How to upload recorded files to a mobile device

Step 1


Launch the Wild Vision App.

Step 2

Pair your optical device and your mobile device via Wi-Fi.

Step 3


Go to the "Device" → "Device storage" menu.



Step 4


Select the photo or video you want to upload by long pressing.


Tap  to upload files to your mobile device.




Clear the download queue

If you need to remove files from the download queue, click the icon  .

Swipe the desired file to the left and click "Delete". Or click the icon  to remove all files from the download queue.





Step 5

Go to the "Gallery" app of your mobile device to check the uploaded files.

How to export and share recorded files via mobile applications

Step 1


Launch the Wild Vision App.

Step 2

Pair your optical device and your mobile device (phone or tablet) via Wi-Fi.


Step 3

Go to the "Device" → "Device storage" menu.



Step 2

Tap one of the uploaded photos or videos you want to share.




Step 3

Tap "Share" icon.



Step 4

Select the desired option in the "Share" menu.



The Wild Vision App allows you to share recorded files via numerous applications installed on your mobile device (social media, mail clients, messengers and cloud storage services) and to save files to your smartphone's internal storage.

Legal Compliances and Disclaimers

The manufacturer reserves the right to make changes to the device software and mobile application at any time, without mandatory prior notice to the Customer (subject to the applicable laws and regulations, if any).

Limitation of Liability. Subject to mandatory applicable laws and regulations: manufacturer will not be liable for any claims, actions, suits, proceedings, costs, expenses, damages or liabilities (if any), arising out of the use of this product. Operation and use of the product are the sole responsibility of the Customer. Manufacturer's sole undertaking is limited to providing the product(s) and related services in accordance with the terms and conditions of concluded transactions, including provisions established in warranty. The provision of products sold and services performed by Manufacturer to the Customer shall not be interpreted, construed, or regarded, either expressly or implied, as being for the benefit of or creating any obligation toward any third party (other than Distributor, Dealer, Buyer). Manufacturer's liability hereunder for damages, regardless of the form or action, shall not exceed the fees or other charges paid to Manufacturer for the product(s) and/or service(s).

MANUFACTURER WILL NOT BE LIABLE FOR LOST REVENUES OR INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES, EVEN IF THE MANUFACTURER KNEW OR SHOULD HAVE KNOWN THAT SUCH DAMAGES WERE POSSIBLE AND EVEN IF DIRECT DAMAGES DO NOT SATISFY A REMEDY.